Zwei L ZweiL SERIES INSTRUCTION MANUAL PUSH LATCH ZL-2901

Thank you for using our product. Before installation, please read this manual thoroughly to ensure correct installation. Please keep this manual at hand for future reference.

FOR YOUR SAFETY AND CORRECT INSTALLATION


Meaning of symbols







Required



\$3.2 \$6.2 Depth of

counter bore

PKL Spacer


(Sold separately)

- Caution If not followed, injury or damage may result.
- This product is for indoor use only. Do not use outside or anywhere where it will be exposed to water.
- Sollow the specified dimensions, specifications, and alignment of the cabinet. Warping, tilting or twisting of the cabinet or door may cause failure.
- \searrow For the prevention of breakage or any other further damage, please do not push the knob in before closing door.
- After repeated usage, the balance of door will weaken, and the item will not work properly. Please readjust the position of either product or door.

COMPONENT PARTS

Packed in the assembled state






3.1 × 10...3 pcs 3.1 × 28...2 pcs


Truss head screw %1 M3 × 25...1 pc

DIMENSIONS




INSTALLATION


Cleaning of machined holes




2 Preparation before assembly



Mounting parts 1



4 Mounting parts 2



PKL Spacer At the time of


installation

-́φ27 9


 $2 \times 3.2 \times 6.2$ 6.2 \times 9.2 Depth of counter bore 2

Recommendable fastening torque: 4 kgf•cm

5 Mounting the counter plate



6 Adjusting counter plate



Close the door and check the latching action and adjust if needed.

OPERATION CHECK

- When the door is closed, the latch is activated and the door is temporarily held.
- · Push in the knob to lock the latch.
- · To unlock the latch, push in the knob again.

